



INSTALLATION INSTRUCTIONS DUNCAN RACING INTERNATIONAL, INC.

CHAIN GUARD

MODEL: HONDA 400EX

Enclosed:

- (1) Chain guard
- (1) 10mm Spacer
- (1) 6mm Spacer
- (2) 6x25 Bolts.

Use 10mm aluminum spacer on top chain guard bolthole behind chain guard. Use 6mm spacer on the bottom hole. Between chain guard and case. Use supplied 6mm bolts. Torque on bolts 7 ft lbs.

After installation, make sure chain guard does not hit chain or countershaft sprocket.

