




VORTEX PERFORMANCE PTY LTD
HEALESVILLE, VICTORIA
AUSTRALIA
WWW.VORTEXCDI.COM

SUZUKI LTR450 06-07 ATV - VORTEX MAP KEY INSTALLATION INSTRUCTIONS

Thank you for purchasing the VORTEX EFI MAP KEY. We hope you will enjoy the benefits of our product. Please follow the below installation instructions carefully.

Step 1: Locate the WHITE 6 WAY connector with the rubber splash cap. This is found on the front of the bike near the top of the RHS Shock absorber. Remove the Rubber splash cap and plug the VORTEX "MAP KEY" onto this connector. See picture below.



MAP KEY FUNCTION

This MAP KEY signals the bikes ECU (Engine Control Unit) to run different Fuel Map. This second Fuel Map enriches the AIR FUEL MIXTURE is only suitable if the bike has been modified by removing the standard Exhaust restrictor and the Airbox lid.

If an aftermarket free flowing pipe is used in conjunction with the removal of the airbox lid and or a filter kit then it will be necessary to install the VORTEX EFI INTERCEPTOR and MAP KEY together. This will result in the correct AIR /FUEL ratio, increase performance and prevent possible engine damage.

NOTE: The VORTEX MAP KEY will also signal the standard ECU to raise the rev limiter from 9,500RPM to 10,490RPM..

INDEMNITY

Note: This is a performance product and is designed for competition use only. The manufacturer or their distributor accepts no responsibility for damage or injury caused by this product. Because we cannot control the application or use of this product, the buyer assumes all risks of any and all damage that may occur to their self, their machinery or third party due to the use of this product. The product is guaranteed against manufacturing defects.